

# Installation on BOBI ROUND stand

BOBI ROUND stand is installed over the mailbox. All fittings and fixing instructions are included in the stand package. You need: A drill, 1/4" or 6 mm drillbit for steel, a vacuum cleaner, a screwdriver, a tape measure and a spade to dig the hole.


We recommend using concrete for a secure and solid installation. Before installing the mailbox to the curbside see the USPS instructions to ensure its correct placement and height at the street. If you are uncertain about the placement please contact your local postoffice prior to your installation.



There are preformed markings for fixing holes on the sides of the mailbox.




Place the letterbox side down on a surface that will not scratch it. Using a 1/4" drillbit for steel...



Drill out the holes with low speed and clean the holes and remove all the metal remnants. Be careful not to scratch the surface. We recommend using a vacuum cleaner to ensure all the small metal parts are removed from the holes, seams and bottom of the letterbox. Otherwise, metal remnants can, over time, start to rust.



All the fittings are provided...



Fasten the parts together from inside the letterbox



Dig ca. 20" deep mounting hole.



Check the level.



Check the height of the letterslot (41"-45" or 100-110 cm)



Fill the mounting hole with gravel or concrete.



You may finish your new letterbox with name & street numbers...



BOBI ROUND stand fits all BOBI mailboxes.